

VENTURA



W 25"
D 27"
H 43"
SH 17"
AH 26"

Ventura
388 : High Back Dining Chair with Arms
Solid teak construction.
Cushion - C28



W 25"
D 25.5"
H 37"
SH 17"
AH 26"

Ventura
383 : Dining Chair with Arms
Solid teak construction.
Cushion - C28



W 18"
D 25"
H 37"
SH 17"

Ventura
395 : Dining Chair
Solid teak construction.
Cushion - C01



W 31.5"
D 40"
H 35"
SH 19.5"
AH 23"

Ventura
224 : Deep Seating Rocking Chair
Teak frame with sling seat panel.
Cushions - Required
See pages 152 to 157 for fabric options



W 31.5"
D 35"
H 31.5"
SH 18.5"
AH 22"

Ventura
220 : Deep Seating Reclining Armchair
Teak frame with sling seat panel.
Back Positions - 3
Cushions - Required
See pages 152 to 157 for fabric options



W 23.5"
D 20.5"
H 16"

Ventura
223 : Deep Seating Ottoman
Solid teak construction.
Cushion - Required
See pages 152 to 157 for fabric options



W 79.5"
D 35"
H 31.5"
SH 18.5"
AH 22"

Ventura
222 : Deep Seating 3-Seater Sofa
Teak frame with sling seat panel.
Cushions - Required
See pages 152 to 157 for fabric options



W 56.5"
D 35"
H 31.5"
SH 18.5"
AH 22"

Ventura
221 : Deep Seating 2-Seater Sofa
Teak frame with sling seat panel.
Cushions - Required
See pages 152 to 157 for fabric options



W 56"
L 75"
H 36"
SH 18.5"
AH 23"

Ventura
226 : Deep Seating Double Chaise
Teak frame with sling seat panel.
Back Positions - 5
Cushion - Required
See pages 152 to 157 for fabric options



W 31.5"
L 75"
H 36"
SH 18.5"
AH 23"

Ventura
225 : Deep Seating Chaise
Teak frame with sling seat panel.
Back Positions - 5
Cushion - Required
See pages 152 to 157 for fabric options